

LIGHTING INSTRUCTION:

1. Open the appliance's lid before lighting!
2. Turn all the appliance's control knobs to the OFF position.
3. Connect the gas cylinder to the barbecue grill (to connect gas cylinder use 37 mBar regulator – when connecting/disconnecting gas cylinder, regulator and hose follow instructions supplied with them).
4. Turn the cylinder valve on. Check the cylinder, regulator and hose connections for leakage using soapy water (see user's manual). Leakage will show as bubbles. If leak is found, do not use the barbecue!
5. To light one of the main burners, push down and turn burner's control knob 90° anti-clockwise (full rate position). An audible click will be heard, this should light the burner. If not, repeat the process. If the burner has not lit after two attempts, turn the cylinder valve off, turn control knobs off and wait 5 minutes before retrying the ignition sequence.
6. When the burner is lit, it can be adjusted by turning the knob between full and low rate position.
7. To light other main burners, follow the 5-6 steps.
8. To light the side burner, open its lid first! Follow 5-6 steps to light the side burner with the use of the side burner control knob.
9. To turn the barbecue off, turn the cylinder valve off. Then, once the flame have extinguished, turn all control knobs on the appliance to the OFF position.

Warning: If any burner fails to ignite twice in a row, turn the cylinder valve off and turn the control knob clockwise to OFF position. Wait 5 minutes before attempting to relight with ignition sequence.

INSTRUKCJA ROZPALANIA GRILLA:

1. Przed rozpaleniem, należy otworzyć pokrywę grilla!
2. Ustawić pokrętła grilla w pozycji OFF.
3. Podłączyć butlę z gazem do grilla (do podłączenia butli gazowej należy użyć reduktora 37 mBar – podczas podłączania/odłączania butli, reduktora oraz węża, należy przestrzegać załączonych do nich instrukcji i wskazówek).
4. Otworzyć zawór butli. Sprawdzić szczelność podłączenia butli, reduktora oraz węża przy użyciu wody z mydłem (zob. instrukcja obsługi). W przypadku nieszczelności, w miejscu wycieku pojawią się pęcherzyki - zabrania się użycia grilla!
5. Aby rozpałić jeden z głównych palników, należy wcisnąć i przekręcić pokrętło danego palnika o 90° odwrotnie do ruchu wskazówek zegara (w pozycję maksymalnej mocy). Słyszalne będzie kliknięcie, palnik zostanie odpalony. Jeśli nie, należy powtórzyć proces. Jeśli dwukrotnie nie udało się odpalić palnika, należy zamknąć zawór butli, ustawić pokrętło w pozycji OFF i odczekać 5 minut przed ponowną próbą rozpalenia.
6. W celu regulacji mocy grzewczej odpalonego palnika, należy ustawić pokrętło pomiędzy pozycją maksymalną a minimalną.
7. Aby zapalić kolejny z głównych palników, należy powtórzyć kroki 5-6.
8. Aby zapalić boczny palnik, należy najpierw podnieść jego pokrywę! Aby rozpałić boczny palnik, należy powtórzyć kroki 5-6 przy użyciu pokrętła bocznego palnika.
9. Aby wyłączyć grilla, należy zamknąć zawór butli. Po zgaśnięciu płomienia, ustawić wszystkie pokrętła na urządzeniu w pozycji OFF.

Ostrzeżenie: jeśli nie uda się rozpałić palnika po dwóch próbach, należy zamknąć zawór butli, a następnie ustawić pokrętło palnika w pozycji OFF. Kolejna próba rozpalenia danego palnika, może być podjęta po upływie 5 minut.