

KWESTIE BEZPIECZEŃSTWA

- Urządzenia nie należy przechowywać w miejscach o zbyt wysokich/zbyt niskich temperaturach.
- Latarkę należy chronić przed płynami i wilgocią.
- Do czyszczenia obudowy latarki, należy używać miękkiej, wilgotnej ściereczki, bez dodatku detergentów.
- Nigdy nie należy kierować promienia świetlnego bezpośrednio na oczy.
- Jeżeli światło jest słabe należy wymienić baterie na nowe.
- Zabrania się własnoręcznej naprawy sprzętu, a także wprowadzania zmian w jego budowie. Jedynie osoby do tego upoważnione i wykwalifikowane mogą naprawiać urządzenie.

OBSŁUGA

- Aby włączyć lub wyłączyć latarkę należy nacisnąć przycisk znajdujący się w dolnej części latarki

**Poland****Prawidłowe usuwanie produktu (zużyty sprzęt elektryczny i elektroniczny)**

Oznaczenie umieszczone na produkcie lub w odnoszących się do niego tekstach wskazuje, że po upływie okresu użytkowania nie należy usuwać z innymi odpadami pochodzącymi z gospodarstw domowych. Aby uniknąć szkodliwego wpływu na środowisko naturalne i zdrowie ludzi wskutek niekontrolowanego usuwania odpadów, prosimy o oddzielenie produktu od innego typu odpadów oraz odpowiedzialny recykling w celu promowania ponownego użycia zasobów materialnych jako stałej praktyki. W celu uzyskania informacji na temat miejsca i sposobu bezpiecznego dla środowiska recyklingu tego produktu użytkownicy w gospodarstwach domowych powinni skontaktować się z punktem sprzedaży detalicznej, w którym dokonali zakupu produktu, lub z organem władz lokalnych. Użytkownicy w firmach powinni skontaktować się ze swoim dostawcą i sprawdzić warunki umowy zakupu. Produktu nie należy usuwać razem z innymi odpadami komercyjnymi.

Wyprodukowano w CHRL dla LECHPOL ELECTRONICS Sp. z o.o. Sp.k., ul. Garwolińska 1, 08-400 Miętle.

SAFETY INSTRUCTIONS

- Avoid using/storing it in extreme temperatures.
- Protect this product from water, humidity or any liquids.
- Use only soft, slightly damp cloth to clean this product. Do not use any chemical agents.
- Do not point light beam directly at eyes.
- If the light is dim, replace the batteries. For new ones.
- Do not attempt to repair/disassemble this appliance yourself. Only authorized and qualified personnel may repair this device.

OPERATION

- To turn the torch on or off, press the button placed on the bottom part of the torch.

**English****Correct Disposal of This Product
(Waste Electrical & Electronic Equipment)**

(Applicable in the European Union and other European countries with separate collection systems) This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.