

## USB Server Compatibility List

MFP / Printer / Scanner										
Update: 8/19/2011										
No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
1	Avision	MF3200	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
2	Avision	MF3230	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
3	BenQ	CM3000	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
4	BenQ	CM3500	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
5	Brother	HL 2040	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
6	Brother	HL 2170W	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
7	Brother	HL 5250DN	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
8	Brother	IntelliFax2820	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
9	Brother	MFC-210C	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
10	Brother	MFC-240C	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
11	Brother	MFC-3820cn	Pass	Pass	-	Pass	Pass	Pass	-	Pass
12	Brother	MFC-3320cn	Pass	N/A	-	Pass	-	N/A	-	Pass
13	Brother	MFC-4800MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
14	Brother	MFC-4800J MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
15	Brother	MFC-6800 MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
16	Brother	MFC-7220 MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
17	Brother	MFC-7420 MFP	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
18	Brother	MFC-7820N MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
19	Brother	MFC-8440 MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
20	Brother	MFC-8840 MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
21	Brother	MFC-8840D MFP	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
22	Canon	CanonScan Lide 5.0	N/A	Pass	N/A	-	N/A	Pass	N/A	-
23	Canon	D660	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
24	Canon	ImageClass MF3110	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
25	Canon	ImageClass MF3112	-	-	-	Pass	-	-	-	Pass
26	Canon	ImageClass MF3220	-	-	-	Pass	-	-	-	Pass
27	Canon	ImageClass MF3222	-	-	-	Pass	-	-	-	Pass
28	Canon	ImageClass MF4010	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
29	Canon	ImageClass MF4150	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
30	Canon	iP100	-	-	-	Pass	-	-	-	Pass
31	Canon	iP1700	Pass	N/A	N/A	-	Pass	N/A	N/A	-
32	Canon	iP2500	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
33	Canon	iP2600	Pass	N/A	N/A	-	Pass	N/A	N/A	-
34	Canon	iP3300	Pass	N/A	N/A	-	Pass	N/A	N/A	-
35	Canon	iP3500	Pass	N/A	N/A	-	Pass	N/A	N/A	-
36	Canon	iP3600	Pass	N/A	N/A	-	Pass	N/A	N/A	-



**MFP / Printer / Scanner**

Update: 8/19/2011

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
76	Canon	MP520	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
77	Canon	MP540	Pass	Pass	Pass	-	Pass	Pass	Pass	-
78	Canon	MP600	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
79	Canon	MP610	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
80	Canon	MP620	Pass	Pass	Pass	-	Pass	Pass	Pass	-
81	Canon	MP630	Pass	Pass	Pass	-	Pass	Pass	Pass	-
82	Canon	MP638	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
83	Canon	MP730	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
84	Canon	MP770	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
85	Canon	MP780	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
86	Canon	MP810	Pass	Pass	-	Pass	-	-	-	Pass
87	Canon	MP830	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
88	Canon	MP960	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
89	Canon	MP970	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
90	Canon	MP980	Pass	Pass	Pass	-	Pass	Pass	Pass	-
91	Canon	MX308	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
92	Canon	PIXMA iP2500	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
93	Canon	PIXMA iP2600	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
94	Canon	PIXMA iP3600	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
95	Canon	PIXMA iP3680	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
96	Canon	PIXMA iP4200	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
97	Canon	PIXMA iP4600	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
98	Canon	PIXMA iP4760	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
99	Canon	PIXMA iP5000	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
100	Canon	PIXMA iP6700D	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
101	Canon	PIXMA MP110	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
102	Canon	PIXMA MP130	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
103	Canon	PIXMA MP145	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
104	Canon	PIXMA MP150	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
105	Canon	PIXMA MP160	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
106	Canon	PIXMA MP170	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
107	Canon	PIXMA MP180	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
108	Canon	PIXMA MP450	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
109	Canon	PIXMA MP530	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
110	Canon	PIXMA MP638	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
111	Canon	PIXMA MP730	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
112	Canon	PIXMA MP780	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
113	Canon	PIXMA MP830	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
114	Canon	PIXMA MX320	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A



No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
154	Epson	PM-A840S	-	-	-	Pass	-	-	-	Pass
155	Epson	PM-A850	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
156	Epson	PM-A890	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
157	Epson	PM-A900	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
158	Epson	PM-A920	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
159	Epson	PM-A940	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
160	Epson	PM-A950	Pass	N/A	Pass	Pass	Pass	N/A	Pass	Pass
161	Epson	PM-A970	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
162	Epson	PM-FA700	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
163	Epson	PM-G4500	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
164	Epson	PM-G5300	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
165	Epson	PM-G860	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
166	Epson	PM-T940	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
167	Epson	PM-T960	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
168	Epson	PM-T990	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
169	Epson	PX-501A	-	-	-	Pass	-	-	-	Pass
170	Epson	PX-5600	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
171	Epson	PX-5800	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
172	Epson	PX-A640	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
173	Epson	PX-A740	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
174	Epson	PX-FA700	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
175	Epson	PX-V780	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
176	Epson	Stylus C43UX	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
177	Epson	Stylus C45	Pass	N/A	N/A	Pass	-	N/A	N/A	Pass
178	Epson	Stylus C60	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
179	Epson	Stylus C61	-	-	-	Pass	-	-	-	Pass
180	Epson	Stylus C65	-	-	-	Pass	-	-	-	Pass
181	Epson	Stylus C66	Pass	N/A	N/A	Pass	-	N/A	N/A	Pass
182	Epson	Stylus C67	-	-	-	Pass	-	-	-	Pass
183	Epson	Stylus C90	-	-	-	Pass	-	-	-	Pass
184	Epson	Stylus CX11F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
185	Epson	Stylus CX-1500	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
186	Epson	Stylus Color 670	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
187	Epson	Stylus CX2900	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
188	Epson	Stylus CX3100	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
189	Epson	Stylus CX3500	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
190	Epson	Stylus CX3700	-	-	-	Pass	-	-	-	Pass
191	Epson	Stylus CX3810	Pass	Pass	N/A	Pass	-	-	N/A	Pass
192	Epson	Stylus CX3900	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass

**MFP / Printer / Scanner**

Update: 8/19/2011

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
193	Epson	Stylus CX4700	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
194	Epson	Stylus CX4800	Pass	-	-	Pass	-	-	-	Pass
195	Epson	Stylus CX4900	Pass	Pass	-	-	Pass	Pass	-	-
196	Epson	Stylus CX5300	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
197	Epson	Stylus CX5500	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
198	Epson	Stylus CX5505	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
199	Epson	Stylus CX5700F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
200	Epson	Stylus CX5900	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
201	Epson	Stylus CX6900F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
202	Epson	Stylus CX7300	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
203	Epson	Stylus CX7800	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
204	Epson	Stylus CX8300	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
205	Epson	Stylus CX9300F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
206	Epson	Stylus CX7803	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
207	Epson	Stylus EC-01	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
208	Epson	Stylus Office TX300F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
209	Epson	Stylus Office TX510F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
210	Epson	Stylus Office TX600F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
211	Epson	Stylus Office TX610F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
212	Epson	Stylus Office TX700F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
213	Epson	Stylus Office TX800F	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
214	Epson	Stylus Photo 1270	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
215	Epson	Stylus Photo 2200	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
216	Epson	Stylus Photo 830	Pass	N/A	N/A	Pass	-	N/A	N/A	-
217	Epson	Stylus Photo 915	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
218	Epson	Stylus Photo R270	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
219	Epson	Stylus Photo RX210	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
220	Epson	Stylus Photo RX430	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
221	Epson	Stylus Photo RX510	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
222	Epson	Stylus Photo RX530	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
223	Epson	Stylus Photo RX630	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
224	Epson	Stylus Photo RX650	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
225	Epson	Stylus Photo RX690	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
226	Epson	Stylus Photo T50	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
227	Epson	Stylus Photo TX700W	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
228	Epson	Stylus Photo TX800FW	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
229	Epson	Stylus R310	Pass	N/A	Pass	Pass	Pass	N/A	Pass	Pass
230	Epson	Stylus R320	Pass	N/A	Pass	Pass	-	N/A	Pass	Pass
231	Epson	Stylus RX510	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
232	Epson	Stylus RX530	Pass	Pass	Pass	-	Pass	Pass	Pass	Pass
233	Epson	Stylus RX590	Pass	Pass	Pass	-	-	-	-	-







## MFP / Printer / Scanner

Update: 8/19/2011

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
323	HP	PhotoSmart C6180	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
324	HP	PhotoSmart C6280	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
325	HP	PhotoSmart C6380	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
326	HP	PhotoSmart C7180	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
327	HP	PhotoSmart C7280	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
328	HP	PhotoSmart C8180	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
329	HP	PhotoSmart D5360	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
330	HP	PhotoSmart D5460	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
331	HP	PhotoSmart D7360	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
332	HP	PhotoSmart Plus B209a	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
333	HP	PhotoSmart Premium C	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
334	HP	PhotoSmart Premium C	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
335	HP	PSC 1510	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
336	HP	PSC 2110	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
337	HP	PSC 2310	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
338	HP	PSC 2355	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
339	HP	PSC 2410	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
340	HP	PSC 2510	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
341	HP	PSC 950	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
342	HP	Deskjet 1125C	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
343	HP	Deskjet 1180C	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
344	HP	Deskjet 1220C	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
345	HP	Deskjet 3745	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
346	HP	Deskjet 5652	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
347	HP	Deskjet 640C	Pass	N/A	N/A	Pass	N/A	N/A	N/A	Pass
348	HP	Deskjet 830C	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
349	HP	Deskjet 920C	Pass	N/A	N/A	-	Pass	N/A	N/A	-
350	HP	Deskjet D2360	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
351	HP	Deskjet D3745	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
352	HP	Deskjet D4160	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
353	HP	Deskjet F300	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
354	HP	Deskjet F340	Pass	-	-	Pass	Pass	-	-	Pass
355	HP	Deskjet F350	Pass	-	-	Pass	Pass	-	-	Pass
356	HP	Deskjet F370	Pass	-	-	Pass	Pass	-	-	Pass
357	HP	Deskjet F379	Pass	-	-	Pass	Pass	-	-	Pass
358	HP	Deskjet F380	Pass	-	-	Pass	Pass	-	-	Pass
359	HP	Deskjet F4185	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
360	HP	LaserJet 1000	Pass	N/A	N/A	-	N/A	N/A	N/A	-
361	HP	LaserJet 1010	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
362	HP	LaserJet 1015	Pass	-	-	Pass	Pass	-	-	N/A
363	HP	LaserJet 1018	Pass	N/A	N/A	NS	Pass	N/A	N/A	NS
364	HP	LaserJet 1020	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
365	HP	LaserJet 1022	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
366	HP	LaserJet 1160	Pass	N/A	N/A	NS	Pass	N/A	N/A	NS
367	HP	LaserJet 2420	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass

**MFP / Printer / Scanner**

Update: 8/19/2011

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
368	HP	LaserJet 2600n	Pass	N/A	N/A	-	-	N/A	N/A	-
369	HP	LaserJet 3015	Pass	Pass	N/A	-	Pass	Pass	N/A	-
370	HP	LaserJet 3050	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
371	HP	LaserJet 3330	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
372	HP	LaserJet M1005	Pass	Pass	N/A	N/A	Pass	Pass	N/A	Pass
373	HP	LaserJet Pro P1102w	Pass	N/A	N/A	-	Pass	N/A	N/A	-
374	HP	LaserJet Pro M1132	Pass	Pass	N/A	-	Pass	Pass	N/A	-
375	HP	Officejet 4255	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
376	HP	Officejet 5510	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
377	HP	Officejet 5610	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
378	HP	Officejet 6210	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
379	HP	Officejet 7210	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
380	HP	Officejet G85	Pass	Pass	N/A	-	Pass	Pass	N/A	-
381	HP	Officejet Pro L7380	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
382	HP	PhotoSmart 2610	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
383	HP	PhotoSmart 3110	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
384	HP	PhotoSmart 3210	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
385	HP	PhotoSmart 3310	-	-	-	Pass	-	-	-	Pass
386	HP	PhotoSmart 335	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
387	HP	PhotoSmart 7830	Pass	N/A	Pass	Pass	Pass	N/A	Pass	Pass
388	HP	PhotoSmart 8030	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
389	HP	PhotoSmart A310	Pass	N/A	N/A	-	Pass	N/A	N/A	-
390	HP	PhotoSmart C3180	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
391	HP	PhotoSmart C5280	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
392	HP	PhotoSmart P1000	Pass	N/A	Pass	-	Pass	N/A	Pass	-
393	HP	PSC 1210	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
394	HP	PSC 1315	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
395	HP	PSC 1350	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
396	HP	PSC 1402	Pass	Pass	-	Pass	Pass	Pass	-	Pass
397	HP	PSC 1410	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
398	HP	PSC 1610	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
399	HP	PSC 2210 All-in-one	Pass	Pass	Pass	-	Pass	Pass	Pass	-
400	HP	Scanjet 4200C	N/A	Pass	N/A	-	N/A	Pass*	N/A	-
401	HP	Scanjet 4370	N/A	PASS	N/A	-	N/A	PASS	N/A	-
402	IBM	Infoprint 1332	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
403	Konica Minota	MC-2430DL	Pass	N/A	N/A	-	-	N/A	N/A	-
404	Konica Minota	Bizhub 160F	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
405	Konica Minota	Bizhub 162	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
406	Konica Minota	Bizhub 210	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
407	Konica Minota	Dialta Di1611	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
408	Konica Minota	MagiColor 2300W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
409	Konica Minota	MagiColor 2400W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
410	Konica Minota	MagiColor 2430DL	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
411	Konica Minota	Magicolor 2500W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A

**MFP / Printer / Scanner**

Update: 8/19/2011

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
412	Konica Minota	MagiColor 5430DL	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
413	Konica Minota	MagiColor 5440DL	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
414	Konica Minota	PagePro 1250W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
415	Konica Minota	PagePro 1300W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
416	Konica Minota	PagePro 1350W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
417	Konica Minota	PagePro 1380MF	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
418	Konica Minota	PagePro 1390MF	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
419	Konica Minota	PagePro 1400W	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
420	KYOCERA	FS-720	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
421	KYOCERA	KM-1635	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
422	KYOCERA	KM-2035	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
423	KYOCERA	P3150	Pass	N/A	N/A	N/A	N/A	N/A	N/A	N/A
424	Lexmark	C750	Pass	N/A	N/A	-	Pass	N/A	N/A	-
425	Lexmark	E120	Pass	N/A	N/A	-	Pass	N/A	N/A	-
426	Lexmark	E210	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
427	Lexmark	P3150	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
428	Lexmark	P4350	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
429	Lexmark	P6250	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
430	Lexmark	P707	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
431	Lexmark	P915	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
432	Lexmark	X1150	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
433	Lexmark	X1185	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
434	Lexmark	X1195	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
435	Lexmark	X1270	Pass	Pass*	N/A	NS	Pass	Pass*	N/A	NS
436	Lexmark	X2250	Pass	Pass	N/A	N/A	Pass	Pass	N/A	Pass
437	Lexmark	X2350	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
438	Lexmark	X2650	Pass	Pass	-	NS	Pass	Pass	-	NS
439	Lexmark	X3330	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
440	Lexmark	X3350	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
441	Lexmark	X3470	Pass	Pass*	Pass	NS	Pass	Pass*	Pass	NS
442	Lexmark	X3550	Pass	Pass*	Pass	NS	Pass	Pass*	Pass	NS
443	Lexmark	X4250	Pass	Pass	-	NS	Pass	Pass	-	NS
444	Lexmark	X4270	Pass	Pass	-	NS	Pass	Pass	-	NS
445	Lexmark	X5150	Pass	Pass	N/A	-	Pass	Pass*	N/A	-
446	Lexmark	X5250	Pass	Pass	N/A	-	Pass	Pass*	N/A	-
447	Lexmark	X5270	Pass	Pass	N/A	-	Pass	Pass*	N/A	-
448	Lexmark	X5470	Pass	Pass	Pass	N/A	Pass	Pass	Pass	N/A
449	Lexmark	X5495	Pass	Pass	-	-	Pass	Pass	-	-
450	Lexmark	X6150	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
451	Lexmark	X6170	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
452	Lexmark	X7170	Pass	Pass*	N/A	NS	Pass	Pass*	N/A	NS
453	Lexmark	X7350	Pass	Pass*	N/A	NS	Pass	Pass*	N/A	NS
454	Lexmark	X8350	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
455	Lexmark	X85	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
456	Lexmark	Z1350	Pass	-	-	-	Pass	-	-	-

**MFP / Printer / Scanner**

Update: 8/19/2011

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
457	Lexmark	Z43	Pass	N/A	N/A	Pass	N/A	N/A	N/A	N/A
458	Lexmark	Z605	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
459	Lexmark	Z645	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
460	Lexmark	Z705	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
461	Lexmark	Z816	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
462	Lexmark	Z55	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
463	Minota	E120	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A
464	OKI	B4100	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
465	OKI	B4351	N/A	N/A	N/A	N/A	Pass	N/A	N/A	Pass
466	OKI	C3200	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
467	OKI	C5600n	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
468	OKI	C5800n	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
469	OKI	Page 8W	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
470	RICOH	Afcio MP 1600	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
471	RICOH	Gestetner MP 1600L	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
472	RICOH	Gestetner MP 2000L	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
473	Samsung	CLP-315	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
474	Samsung	CLP-620ND	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
475	Samsung	CLX-2160	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
476	Samsung	CLX-3175	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
477	Samsung	Laser MFP SF-560	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
478	Samsung	Laser MFP SF-565P	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
479	Samsung	ML-1210	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
480	Samsung	ML-1610	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
481	Samsung	ML-1660	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
482	Samsung	ML-1710	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
483	Samsung	ML-1750	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
484	Samsung	ML-2010	Pass	N/A	N/A	Pass	Pass	N/A	N/A	NS
485	Samsung	ML-2580N	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
486	Samsung	ML-3471ND	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
487	Samsung	SCX 4016	Pass	N/A	N/A	Pass	Pass	N/A	N/A	Pass
488	Samsung	SCX-4100	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
489	Samsung	SCX-4106	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
490	Samsung	SCX-4116	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
491	Samsung	SCX-4200	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
492	Samsung	SCX-4216F	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
493	Samsung	SCX 4500	Pass	Pass	N/A	Pass	Pass	Pass	N/A	Pass
494	Samsung	SCX-4521F	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
495	Samsung	SCX-4720F	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
496	SHARP	AM-400	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
497	SHARP	AR-5316	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
498	SHARP	AR-M205	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
499	SHARP	AR-M207	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
500	SHARP	AR-M209	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
501	SHARP	AR-M276	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A

No	Brand	Model Name	Windows XP				Windows Vista / Windows 7			
			Print	Scan	Card Reader	LPR*	Print	Scan	Card Reader	LPR*
502	TECO	DOCUJET 3516	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
503	TECO	DOCUJET 4016	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
504	TECO	DOCUJET 4021	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
505	TECO	DOCUJET UA-1610F	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
506	TECO	DOCUJET UA3816	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
507	TECO	DOCUJET UA3820	Pass	Pass	N/A	N/A	Pass	Pass	N/A	N/A
508	TOSHIBA	Estudio-165	Pass	N/A	N/A	N/A	Pass	N/A	N/A	N/A

**N/A : This USB Device does not have this function**

**- : Not Test (Only a certain function of this device was tested)**

**NS: This function is not supported.**

Remark:

1. Scan: Pass\* means pass either by Utility Scan or MS Paint Scan

## USB Server Compatibility List

DV / DSC / Cell Phone						
No	Brand	Model Name	XP		Vista	
			Read	Wirte	Read	Wirte
<b>DV</b>						
1	Sanyo	VPC-C4	Pass	Pass	-	-
2	Sony	DCR-SR200	Pass	Pass	Pass	Pass
3	Sony	DCR-SR300	Pass	Pass	Pass	Pass
4	Sony	DCR-SR62	Pass	Pass	Pass	Pass
5	Sony	DCR-SR82	Pass	Pass	Pass	Pass
6	Sony	HDR-CX7	Pass	Pass	Pass	Pass
7	Sony	HDR-CX7K	Pass	Pass	Pass	Pass
8	Sony	HDR-SR5	Pass	Pass	Pass	Pass
9	Sony	HDR-SR7	Pass	Pass	Pass	Pass
10	Sony	HDR-SR8	Pass	Pass	Pass	Pass
<b>DSC</b>						
11	AIPTEK	DV M2	Pass	Pass	Pass	Pass
12	Canon	A640	Pass	Pass	Pass	Pass
13	Canon	EOS 350D	Pass	Pass	-	-
14	Canon	IXUS 400	Pass	Pass	-	-
15	Canon	IXUS 500	Pass	Pass	Pass	Pass
16	Canon	IXUS 65	Pass	Pass	Pass	Pass
17	Canon	IXUS 860IS	Pass	Pass	Pass	Pass
18	Canon	PowerShot A640	Pass	Pass	-	-
19	Canon	PowerShot G5	Pass	Pass	Pass	Pass
20	Canon	PowerShot S30	Pass	Pass	-	-
21	Canon	PowerShot S3IS	Pass	Pass	-	-
22	Canon	PowerShot S400	Pass	Pass	-	-
23	Canon	Pro90IS	Pass	Pass	-	-
24	Casio	Exilim EX-Z40	Pass	Pass	-	-
25	Casio	Exilim EX-Z55	Pass	Pass	Pass	Pass
26	Casio	QV-R62	Pass	Pass	-	-
27	Fujifilm	FinePix A310	Pass	Pass	-	-
28	Fujifilm	FinePix S5000	Pass	Pass	-	-
29	Fujifilm	FinePix S602	Pass	Pass	-	-
30	Fujifilm	FinePix S9500	Pass	Pass	Pass	Pass
31	Kodak	CX6330	Pass	Pass	-	-
32	Minolta	DiMAGE F200	Pass	Pass	Pass	Pass
33	Minolta	DiMAGE Xt	Pass	Pass	-	-
34	Nikon	Coolpix 3100	Pass	Pass	-	-

DV / DSC / Cell Phone						
No	Brand	Model Name	XP		Vista	
			Read	Wirte	Read	Wirte
35	Nikon	Coolpix 3200	Pass	Pass	-	-
36	Nikon	Coolpix 5900	Pass	Pass	-	-
37	Nikon	D100	Pass	Pass	-	-
38	Nikon	D40	Pass	Pass	-	-
39	Olympus	C-2	Pass	Pass	-	-
40	Olympus	C-720	Pass	Pass	-	-
41	Olympus	C-740	Pass	Pass	-	-
42	Olympus	μ1000	Pass	Pass	-	-
43	Olympus	μ300	Pass	Pass	-	-
44	Olympus	μ410	Pass	Pass	-	-
45	Panasonic	DMC FX1	Pass	Pass	Pass	Pass
46	Panasonic	LUMIX F7 (DMC-F7)	Pass	Pass	-	-
47	Panasonic	LUMIX FX7 (DMC-FX07GT)	Pass	Pass	-	-
48	Panasonic	LUMIX FX9 (DMC-FX9)	Pass	Pass	-	-
49	Panasonic	LUMIX FZ20 (DMC-FZ20)	Pass	Pass	-	-
50	Panasonic	LUMIX LC33	Pass	Pass	-	-
51	Panasonic	LUMIX LX2	Pass	Pass	-	-
52	Pentax	OPTIO M10	Pass	Pass	-	-
53	Richo	Caplio-R4	Pass	Pass	-	-
54	Sony	DSC-H3	Pass	Pass	Pass	Pass
55	Sony	DSC-H5	Pass	Pass	Pass	Pass
56	Sony	DSC-H9	Pass	Pass	Pass	Pass
57	Sony	DSC-P10	Pass	Pass	Pass	Pass
58	Sony	DSC-P200	Pass	Pass	Pass	Pass
59	Sony	DSC-T1	Pass	Pass	Pass	Pass
60	Sony	DSC-T2	Pass	Pass	Pass	Pass
61	Sony	DSC-T200	Pass	Pass	Pass	Pass
62	Sony	DSC-T70	Pass	Pass	Pass	Pass
63	Sony	DSC-T9	Pass	Pass	Pass	Pass
64	Sony	DSC-W1	Pass	Pass	Pass	Pass
65	Sony	DSC-W200	Pass	Pass	Pass	Pass
66	Sony	DSC-W80	Pass	Pass	Pass	Pass
67	Sony	DSLR-A200	Pass	Pass	Pass	Pass
68	Sony	DSLR-A700	Pass	Pass	Pass	Pass
69	Sony	NSC-GC1	Pass	Pass	Pass	Pass
<b>Cell Phone</b>						
70	Nokia	6233	Pass	Pass	Pass	Pass

N/A : This USB Device does not have this function

- : Not Test (Only a certain function of this device was tested)

<b>DV / DSC / Cell Phone</b>						
<b>No</b>	<b>Brand</b>	<b>Model Name</b>	<b>XP</b>		<b>Vista</b>	
			<b>Read</b>	<b>Wirte</b>	<b>Read</b>	<b>Wirte</b>

**NS: This function is not supported.**



## USB Server Compatibility List

Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floopy Disk / USB 2.0 Hub / Others							
No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
<b>Hard Disk</b>							
1	Airlink	USB Enclosure (AEN-U55)	Pass	Pass	-	-	
2	Benq	EW1621	Pass	Pass	-	-	
3	Buffalo	HD-PH80U2/UC-BK	Pass	Pass	Pass	Pass	
4	Corega	CG-U2HDC25	Pass	Pass	-	-	
5	Cypress	Cypress Semiconductor USB2.0 Storage	Pass	Pass	Pass	Pass	
6	Edge	EDGDC-196318-PE DiskGO 20GB USB HDD	Pass	Pass	Pass	Pass	
7	Genuine	Scopio	Pass	Pass	-	-	
8	Hitachi	2.5" USB HDD	Pass	Pass	Pass	Pass	
9	Initio	MHW2160BH PL	Pass	Pass	Pass	Pass	
10	IO Data	HDPG-SU80	Pass	Pass	-	-	
11	IOGear	eSATA/USB2.0	Pass	Pass	Pass	Pass	
12	IOGear	Firewire / USB 2.0 External HDD	Pass	Pass	NS	NS	
13	Jmicron	USB to ATA/ATAPI Bridge	Pass	Pass	Pass	Pass	
14	LaCie	Starck desktop 1TB 3.5 inches	Pass	Pass	Pass	Pass	
15	Logitech	LHD-ED1000FU2	Pass	Pass	Pass	Pass	
16	Logitech	LHD-ED1000SAU2	Pass	Pass	Pass	Pass	
17	Logitech	LHD-ED1000U2	Pass	Pass	Pass	Pass	
18	Logitech	LHD-ED250FU2	Pass	Pass	Pass	Pass	
19	Logitech	LHD-ED250SAU2	Pass	Pass	Pass	Pass	
20	Logitech	LHD-ED250U2	Pass	Pass	Pass	Pass	
21	Logitech	LHD-ED300FU2	Pass	Pass	Pass	Pass	
22	Logitech	LHD-ED300U2	Pass	Pass	Pass	Pass	
23	Logitech	LHD-ED320SAU2	Pass	Pass	Pass	Pass	
24	Logitech	LHD-ED320U2	Pass	Pass	Pass	Pass	
25	Logitech	LHD-ED400FU2	Pass	Pass	Pass	Pass	
26	Logitech	LHD-ED400SAU2	Pass	Pass	Pass	Pass	
27	Logitech	LHD-ED400U2	Pass	Pass	Pass	Pass	
28	Logitech	LHD-ED500FU2	Pass	Pass	Pass	Pass	
29	Logitech	LHD-ED500SAU2	Pass	Pass	Pass	Pass	
30	Logitech	LHD-ED500U2	Pass	Pass	Pass	Pass	
31	Logitech	LHD-ED640FU2	Pass	Pass	Pass	Pass	
32	Logitech	LHD-ED640SAU2	Pass	Pass	Pass	Pass	
33	Logitech	LHD-ED640U2	Pass	Pass	Pass	Pass	
34	Logitech	LHD-ED750FU2	Pass	Pass	Pass	Pass	
35	Logitech	LHD-ED750SAU2	Pass	Pass	Pass	Pass	

**Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floppy Disk / USB 2.0 Hub / Others**

No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
36	Logitech	LHD-ED750U2	Pass	Pass	Pass	Pass	
37	Logitech	LHD-HB250FU2	Pass	Pass	Pass	Pass	
38	Logitech	LHD-HB250U2	Pass	Pass	Pass	Pass	
39	Logitech	LHD-HB300FU2	Pass	Pass	Pass	Pass	
40	Logitech	LHD-HB300U2	Pass	Pass	Pass	Pass	
41	Logitech	LHD-HB320FU2	Pass	Pass	Pass	Pass	
42	Logitech	LHD-HB320U2	Pass	Pass	Pass	Pass	
43	Logitech	LHD-HB400FU2	Pass	Pass	Pass	Pass	
44	Logitech	LHD-HB400U2	Pass	Pass	Pass	Pass	
45	Logitech	LHD-HB500FU2	Pass	Pass	Pass	Pass	
46	Logitech	LHD-HB500U2	Pass	Pass	Pass	Pass	
47	Logitech	LHD-HB750FU2	Pass	Pass	Pass	Pass	
48	Logitech	LHD-HB750U2	Pass	Pass	Pass	Pass	
49	Logitech	LHD-HBS1000U2	Pass	Pass	Pass	Pass	
50	Logitech	LHD-HBS250FU2	Pass	Pass	Pass	Pass	
51	Logitech	LHD-HBS250SAU2	Pass	Pass	Pass	Pass	
52	Logitech	LHD-HBS250U2	Pass	Pass	Pass	Pass	
53	Logitech	LHD-HBS300FU2	Pass	Pass	Pass	Pass	
54	Logitech	LHD-HBS300SAU2	Pass	Pass	Pass	Pass	
55	Logitech	LHD-HBS300U2	Pass	Pass	Pass	Pass	
56	Logitech	LHD-HBS320FU2	Pass	Pass	Pass	Pass	
57	Logitech	LHD-HBS320SAU2	Pass	Pass	Pass	Pass	
58	Logitech	LHD-HBS320U2	Pass	Pass	Pass	Pass	
59	Logitech	LHD-HBS400FU2	Pass	Pass	Pass	Pass	
60	Logitech	LHD-HBS400SAU2	Pass	Pass	Pass	Pass	
61	Logitech	LHD-HBS400U2	Pass	Pass	Pass	Pass	
62	Logitech	LHD-HBS500FU2	Pass	Pass	Pass	Pass	
63	Logitech	LHD-HBS500SAU2	Pass	Pass	Pass	Pass	
64	Logitech	LHD-HBS500U2	Pass	Pass	Pass	Pass	
65	Logitech	LHD-HBS640U2	Pass	Pass	Pass	Pass	
66	Logitech	LHD-HBS750FU2	Pass	Pass	Pass	Pass	
67	Logitech	LHD-HBS750SAU2	Pass	Pass	Pass	Pass	
68	Logitech	LHD-HBS750U2	Pass	Pass	Pass	Pass	
69	Logitech	LHD-PBE120U2BK	Pass	Pass	Pass	Pass	
70	Logitech	LHD-PBE120U2SV	Pass	Pass	Pass	Pass	
71	Logitech	LHD-PBE120U2WH	Pass	Pass	Pass	Pass	
72	Logitech	LHD-PBE160U2BK	Pass	Pass	Pass	Pass	
73	Logitech	LHD-PBE160U2SV	Pass	Pass	Pass	Pass	
74	Logitech	LHD-PBE160U2WH	Pass	Pass	Pass	Pass	

**Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floppy Disk / USB 2.0 Hub / Others**

No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
75	Logitech	LHD-PBE40U2BK	Pass	Pass	Pass	Pass	
76	Logitech	LHD-PBE40U2SV	Pass	Pass	Pass	Pass	
77	Logitech	LHD-PBE40U2WH	Pass	Pass	Pass	Pass	
78	Logitech	LHD-PBE80U2BK	Pass	Pass	Pass	Pass	
79	Logitech	LHD-PBE80U2SV	Pass	Pass	Pass	Pass	
80	Logitech	LHD-PBE80U2WH	Pass	Pass	Pass	Pass	
81	Logitech	LHD-PBF120FU2SV	Pass	Pass	Pass	Pass	
82	Logitech	LHD-PBF160FU2SV	Pass	Pass	Pass	Pass	
83	Logitech	LHD-PBF250FU2SV	Pass	Pass	Pass	Pass	
84	Logitech	LHD-PBF320FU2SV	Pass	Pass	Pass	Pass	
85	Logitech	LHD-PHA120FU2	Pass	Pass	Pass	Pass	
86	Logitech	LHD-PHA120U2	Pass	Pass	Pass	Pass	
87	Logitech	LHD-PHA160FU2	Pass	Pass	Pass	Pass	
88	Logitech	LHD-PHA160U2	Pass	Pass	Pass	Pass	
89	Logitech	LHD-PHA80FU2	Pass	Pass	Pass	Pass	
90	Logitech	LHD-PHA80U2	Pass	Pass	Pass	Pass	
91	Logitech	LHD-PS80U2WH	Pass	Pass	Pass	Pass	
92	Logitech	LHD-PSA120U2SV	Pass	Pass	Pass	Pass	
93	Mastor	Mastor Basics External Hard Drive (250G)	Pass	Pass	Pass	Pass	
94	Mastor	Mastor Basics External Hard Drive (500G)	Pass	Pass	Pass	Pass	
95	Mobile Disk	HD-338-U2C	Pass	Pass	-	-	
96	NetDisk	NDAS ND10	Pass	Pass	-	-	
97	NuSLIM	PL-2506	Pass	Pass	-	-	
98	Philips	Mobile Storage Drive (300G)	Pass	Pass	Pass	Pass	
99	Philips	USB 2.0 Mobile Disk(SPD5220CC/96S)	Pass	Pass	Pass	Pass	
100	Prolific	Prolific Technology ING (160G)	Pass	Pass	Pass	Pass	
101	RDC	RDC2882	Pass	Pass	-	-	
102	Sunplus	USB to Serial-ATA Bridge	Pass	Pass	Pass	Pass	
103	Teac	HD-231	Pass	Pass	-	-	
104	Transcend	2.5" HDD	Pass	Pass	Pass	Pass	
105	Transcend	StoreJet 2.5" 120G HDD	Pass	Pass	Pass	Pass	
106	Transcend	StoreJet 25C 320GB	Pass	Pass	Pass	Pass	
107	Transcend	StoreJet TS30GSJ18 30GB USB HDD	Pass	Pass	Pass	Pass	
108	Transcend	StoreJet TS40GSJ25B USB HDD	Pass	Pass	Pass	Pass	
109	Vantec	Nexstar.3 External 3.5" Hard Drive Enclosure	Pass	Pass	Pass	Pass	
110	VIA	USB to IDE Bridge	Pass	Pass	Pass	Pass	
111	Vipower	VPA-25289	Pass	Pass	-	-	
112	Xander	X-Note 2.5" 160G SATA Mobile Disk(Black)	Pass	Pass	Pass	Pass	
113	Zynet	HD-D4-U2SA	Pass	Pass	Pass	Pass	

**Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floppy Disk / USB 2.0 Hub / Others**

No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
114	Zynet	HD-D5-U2FW	Pass	Pass	Pass	Pass	
<b>Card Reader</b>							
115	Alcor	Single Slot SD/MMC/SD-HC Card Reader	Pass	Pass	Pass	Pass	
116	Elecom	MR-A10BK	Pass	Pass	Pass	Pass	
117	Elecom	MR-A10GN	Pass	Pass	Pass	Pass	
118	Elecom	MR-A10GY	Pass	Pass	Pass	Pass	
119	Elecom	MR-A10WH	Pass	Pass	Pass	Pass	
120	Elecom	MR-A11HWH	Pass	Pass	Pass	Pass	
121	Elecom	MR-A13HSV	Pass	Pass	Pass	Pass	
122	Elecom	MR-A14HBK	Pass	Pass	Pass	Pass	
123	Elecom	MR-A14HBU	Pass	Pass	Pass	Pass	
124	Elecom	MR-A14HSV	Pass	Pass	Pass	Pass	
125	Elecom	MR-A14HWH	Pass	Pass	Pass	Pass	
126	Elecom	MR-A20HBK	Pass	Pass	Pass	Pass	
127	Elecom	MR-A20HBU	Pass	Pass	Pass	Pass	
128	Elecom	MR-A20HRD	Pass	Pass	Pass	Pass	
129	Elecom	MR-A20HSV	Pass	Pass	Pass	Pass	
130	Elecom	MR-A20HWH	Pass	Pass	Pass	Pass	
131	Elecom	MR-A33HBK	Pass	Pass	Pass	Pass	
132	Elecom	MR-A33HSV	Pass	Pass	Pass	Pass	
133	Elecom	MR-A33HWH	Pass	Pass	Pass	Pass	
134	Elecom	MR-A47HBK	Pass	Pass	Pass	Pass	
135	Elecom	MR-A47HSV	Pass	Pass	Pass	Pass	
136	Elecom	MR-A47HWH	Pass	Pass	Pass	Pass	
137	Elecom	MR-C10BK	Pass	Pass	Pass	Pass	
138	Elecom	MR-C10SV	Pass	Pass	Pass	Pass	
139	Elecom	MR-C10WH	Pass	Pass	Pass	Pass	
140	Elecom	MR-C11BK	Pass	Pass	Pass	Pass	
141	Elecom	MR-C11RD	Pass	Pass	Pass	Pass	
142	Elecom	MR-C11SV	Pass	Pass	Pass	Pass	
143	Elecom	MR-C11WH	Pass	Pass	Pass	Pass	
144	Elecom	MR-C12BK	Pass	Pass	Pass	Pass	
145	Elecom	MR-C12BU	Pass	Pass	Pass	Pass	
146	Elecom	MR-C12RD	Pass	Pass	Pass	Pass	
147	Elecom	MR-C12WH	Pass	Pass	Pass	Pass	
148	Elecom	MR-C13BK	Pass	Pass	Pass	Pass	
149	Elecom	MR-C13WH	Pass	Pass	Pass	Pass	
150	Elecom	MR-SMC01BK	Pass	Pass	Pass	Pass	
151	Elecom	MR-SSD01BK	Pass	Pass	Pass	Pass	

**Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floppy Disk / USB 2.0 Hub / Others**

No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
152	E-Sense	SCR200	Pass	Pass	Pass	Pass	
153	Galileo	23-in-1 Card Reader	Pass	Pass	-	-	
154	Genesys	SD Cad Reader Genesys Logic	Pass	Pass	Pass	Pass	
155	Moai	SDMMC M121	Pass	Pass	Pass	Pass	
156	Myson Century	CF Card Reader USB2.0	Pass	Pass	Pass	Pass	
157	No Brand	6 in 1 Card Reader (CR-V1102-U26)	Pass	Pass	Pass	Pass	
158	No Brand	Media Reader USB 2.0	Pass	Pass	Pass	Pass	
159	Philips	SD/Mini SD/MMC Card Reader	Pass	Pass	Pass	Pass	
160	Samsung	TRUTION TUH-7000X	Pass	Pass	-	-	
161	SanDisk	SDDR-113	Pass	Pass	Pass	Pass	
162	Sanwa	ADR-MLT1W	Pass	Pass	Pass	Pass	
163	SMSC	USB to Flash Device	Pass	Pass	Pass	Pass	
164	SUNZone	SUZCR920	Pass	Pass	N/A	N/A	
165	Teac	US-4SM-B	Pass	Pass	-	-	
166	Transcend	TS-RD13B, 13-in-1 Card Reader	Pass	Pass	-	-	
167	VIA	USB2.0 Card Reader	Pass	Pass	Pass	Pass	
<b>VCD / DVD RW</b>							
168	Benq	DVD-RW (EW-1621)	Pass	Pass	Pass	Pass	
169	Benq	DVD-RW (EW-164B)	Pass	Pass	Pass	Pass	
170	Buffalo	DVD Writer (DVSM-XL1218U2)	Pass	Pass	Pass	Pass	
171	IO Data	DVR-UEM16CR	Pass	Pass	-	-	
172	Logitec	LDR-MA18U2	Pass	Pass	-	-	
173	Logitec	LDR-PMD8U2	Pass	Pass	Pass	Pass	
174	Pioneer	Pioneer MULTI Recorder	Pass	Pass	Pass	Pass	
175	Sony	DRX-100UL	Pass	Pass	-	-	
<b>MP3</b>							
176	Apia	APIA MP3 Player	Pass	Pass	Pass	Pass	
177	Apple	iPod 30G	Pass	Pass	Pass	Pass	
178	Apple	iPod Mini	Pass	Pass	-	-	
179	Apple	iPod Video	Pass	Pass	Pass	Pass	
180	Apple	iPod shuffle	-	-	-	-	
181	Apple	iPod nano	-	-	-	-	
182	Apple	iPod classic	-	-	-	-	
183	Apple	iPod touch	-	-	-	-	
184	Apple	iPhone 2G	-	-	-	-	
185	Apple	iPhone 3G	-	-	-	-	
186	Greative	MuVO TX FM	Pass	Pass	Pass	Pass	
187	Isito	IS-901B	Pass	Pass	Pass	Pass	
188	MP4 digital player	F630	Pass	Pass	Pass	Pass	

**Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floppy Disk / USB 2.0 Hub / Others**

No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
189	Mpio	FG100	Pass	Pass	Pass	Pass	
190	Samsung	YP-E3 MP3 Player	Pass	Pass	Pass	Pass	
191	Sony	NW-A806	Pass	Pass	Pass	Pass	
192	Sony	NWD-B103F	Pass	Pass	Pass	Pass	
193	Sony	NW-E013	Pass	Pass	Pass	Pass	
194	Sony	NWZ-S615F	Pass	Pass	Pass	Pass	
<b>Flash Drive</b>							
195	Adata	MyFlash USB2.0 1GB	Pass	Pass	-	-	
196	Adata	MyFlash USB2.0 512MB RB15	Pass	Pass	-	-	
197	Apacer	Handy	Pass	Pass	Pass	Pass	
198	Buffalo	RUF2-S512-BK	Pass	Pass	-	-	
199	Elecom	USB Flash 128MB	Pass	Pass	-	-	
200	IO Data	ToteBag TB-BH512/B	Pass	Pass	-	-	
201	Kingston	DataTraveler 1GB	Pass	Pass	Pass	Pass	
202	Kingston	DataTraveler 2.0 1GB	Pass	Pass	Pass	Pass	
203	Lexar	FireFly (JDFF512-431)	Pass	Pass	-	-	
204	PNY	PNY Attache 2.0	Pass	Pass	Pass	Pass	
205	Pqi	Flash Disk 1G	Pass	Pass	Pass	Pass	
206	SanDisk	Cruzer Contour 4G	Pass	Pass	Pass	Pass	
207	SanDisk	Cruzer Contour 8G	Pass	Pass	Pass	Pass	
208	SanDisk	Cruzer Micro 1G	Pass	Pass	Pass	Pass	
209	SanDisk	Cruzer Micro 4G	Pass	Pass	Pass	Pass	
210	SanDisk	Cruzer Mini 128M	Pass	Pass	Pass	Pass	
211	Slicon Power	Touch Series USB Flash Drive 1G	Pass	Pass	Pass	Pass	
212	Sony	POCKETBIT USM512J	Pass	Pass	-	-	
213	Sony	USM2GJ	Pass	Pass	Pass	Pass	
214	Sony	USM4GJX	Pass	Pass	Pass	Pass	
215	TD Star	TD Star USB Drive	Pass	Pass	Pass	Pass	
216	Transcend	JetFlash 1GB	Pass	Pass	Pass	Pass	
218	Transcend	JetFlash 300 32GB					
217	Transcend	JetFlash 512MB	Pass	Pass	Pass	Pass	
219	Transcend	JF130 1GB	Pass	Pass	Pass	Pass	
220	Transcend	JF168 1GB	Pass	Pass	Pass	Pass	
221	Transcend	JFV30 1GB	Pass	Pass	Pass	Pass	
<b>Floppy Disk</b>							
222	Acer	YD-8U10	Pass	Pass	Pass	Pass	
223	Mitsumi	D343GUE	Pass	Pass	Pass	Pass	
224	Mitsumi	D353FUE	Pass	Pass	Pass	Pass	
225	Mitsumi	USB FDD	Pass	Pass	Pass	Pass	

Hard Disk / Card Reader / DVD RW / MP3 / Flash Drive / Floppy Disk / USB 2.0 Hub / Others							
No	Brand	Model Name	XP		VISTA		Remark
			Read	Wirte	Read	Wirte	
<b>USB 2.0 Hub</b>							
226	Adaptec	Hi-Speed 4 Ports USB HUB	Pass	Pass	Pass	Pass	
227	GoodTek	GH-201 USB 2.0 4 Ports Hub	Pass	Pass	Pass	Pass	
228	Hewlett-Packard	DG954A 4 Port USB2.0 HUB	Pass	Pass	-	-	
229	I-Rocks	IR-4370 Hub	Pass	Pass	Pass	Pass	
230	KINYO	HUB-3 Pro2007314211459	Pass	Pass	Pass	Pass	
231	No Brand	Mini 4 Ports Hub BP-07000153	Pass	Pass	Pass	Pass	
232	Nstyle	Chip: Genesys Logic Inc	Pass	Pass	Pass	Pass	
233	Samsung	Pleomax PUH-7000X	Pass	Pass	Pass	Pass	
<b>Others</b>							
234	DigiMatelll	INSTEP EX-SRIVE	Pass	Pass	Pass	Pass	Photo Bank
235	MagicPixel	MP612B	Pass*1	Pass*1	Pass*1	Pass*1	Photo Frame
236	Sony	PSP	Pass	Pass	Pass	Pass	PlayStation Portable

**N/A : This USB Device does not have this function**  
**- : Not Test (Only a certain function of this device was tested)**  
**NS: This function is not supported.**  
 Remark:  
 Pass\*1: USB device signal issue, only at full speed.

## USB Audio / USB Phone / USB Display / USB Webcam

No	Brand	Model Name	XP	Vista
<b>USB Audio</b>				
1	3D Sound	PU552	Pass	Pass
2	3D Sound	USB 2.0 3D Audio Sound Card Adapter Virtual 5.1 SC18	Pass	Pass
3	Creative	Labs Sound Blaster Digital Music SX	Pass	Pass
4	ESMT	USB Speaker USB-269A	Pass	Pass
5	Genius	USB Audio Device	Pass	Pass
6	Hewlett-Packard	Multi-media Speakers	Pass	Pass
7	Intopic	Jazz USB Headphone Set	Pass	Pass
8	JS	USB Speaker J-6502	Pass	Pass
9	Kuro	USB Speaker KUP 700	Pass	Pass
10	Lemel	USB Speaker	Pass	Pass
11	Logitech	LRT-FMAM100U	Pass	Pass
12	Logitech	V20 Notebook Speakers	Pass	Pass
13	Mediatek	C-Media USB Headphone Set	Pass	Pass
14	Samsung	USB-335E	Pass	Pass
15	TI	TI USB Audio DAC	Pass	Pass
16	Turtle Beach	Audio Advantage Micro	Pass	Pass
<b>USB Phone</b>				
17	Aipotek	VP-0002	Pass	Pass
18	Corega	Advanced USB Phone CG-USBPH02	Pass	Pass
19	Ipevo	CDPU-04IP	Pass	Pass
<b>USB Display</b>				
20	Asus	UF735	Pass	Pass
21	DisplayLink	DL-120	Pass	Pass
22	DisplayLink	DL-160	Pass	Pass
23	Neonplus	USB2.0 VGA Adapter	Pass	Pass
24	No Brand	UVT100	Pass	Pass
<b>USB WebCam**</b>				
25	Andymay	CD-06 (USB 2.0)	Pass	Pass
26	Andymay	CD-07 (USB 1.1)	Pass	Pass
27	Creative	Live!Cam Video IM Skype Edition (USB 1.1)	Pass	Pass
28	Elecom	UCAM-DLM130	Pass	Pass
29	Elecom	UCAM-DLM130HPN	Pass	Pass
30	Elecom	UCAM-DLM130HSV	Pass	Pass
31	Elecom	UCAM-DLM130HWH	Pass	Pass
32	Elecom	UCAM-DLQ30	Pass	Pass
33	Elecom	UCAM-DLS30HBK	Pass	Pass
34	Elecom	UCAM-DLS30HPN	Pass	Pass
35	Elecom	UCAM-DLS30HSV	Pass	Pass
36	Elecom	UCAM-E130HBU	Pass	Pass
37	Elecom	UCAM-E130HSV	Pass	Pass



## USB Audio / USB Phone / USB Display / USB Webcam

No	Brand	Model Name	XP	Vista
38	Elecom	UCAM-E130HWH	Pass	Pass
39	Elecom	UCAM-E130HWH	Pass	Pass
40	Empia	JHY107	Pass	Pass
41	Gdmall	Cyber Cam Max (USB 1.1)	Pass	Pass
42	Intopic	Web Live620-W (USB 2.0)	Pass	N/A
43	Intopic	Web Live660-G (USB 1.1)	Pass	Pass
44	Ipevo	Ipevo POV CDVU-02IP	Pass	Pass
45	Kinyo	My EZCam PCM-531 (USB 1.1)	Pass	Pass
46	Logitech	QuickCam Chat(快看分享版)	Pass	Pass
47	Logitech	QuickCam Chat(快看聊天室) (USB 1.1)	Pass	N/A
48	Logitech	QuickCam Communication STX	Pass	Pass
49	Logitech	QuickCam Pro 3000	Pass	N/A
50	Microsoft	LifeCam VX-3000 (USB 1.1)	Pass	Pass
51	Microsoft	LifeCam VX-7000 (USB 2.0)	Pass	Pass
52	Nstyle	NWC-532 (USB 2.0)	Pass	Pass
53	ORITE	MB-630 (USB 1.1)	Pass	N/A
54	Philips	Webcam SPC500NC (USB 1.1)	Pass	Pass
55	Ronald	Digital Camera L-1 (PC222) (USB 2.0)	Pass	Pass
56	T.C.Star	TCB-P262 (USB 2.0)	Pass	Pass
57	T.C.Star	TCB-A322 (USB 2.0)	Pass	Pass
58	TASCORP	JPEG USB Video Camera (USB 1.1)	Pass	N/A
59	V-Gear	TalkCam Live AMVG1-010-063-02-G (USB 1.1)	Pass	Pass

**\*\*Web cam not supported when it connected through a USB Hub. NOTE: If the E1868 product comes with more than one USB port, then it has a build-in USB**

**N/A : This USB Device does not have this function**

**- : Not Test (Only a certain function of this device was tested)**

**NS: This function is not supported.**

<b>Mouse / Keyboard / Joystick</b>				
<b>No</b>	<b>Brand</b>	<b>Model Name</b>	<b>XP</b>	<b>Vista</b>
<b>Mouse</b>				
1	Acer	GM-03024A	Pass	Pass
2	Acer	NB Mouse	Pass	Pass
3	DELL	M056U0	Pass	Pass
4	Detroit	PS/2 + USB Mouse	Pass	Pass
5	HP	M-UAE96	Pass	Pass
6	HP	M-UV94	Pass	Pass
7	IBM	USB Device 04B3	Pass	Pass
8	Lemel	M857C	Pass	Pass
9	Logitech	M-BB48	Pass	Pass
10	Logitech	M-BD53	Pass	Pass
11	Logitech	MX310	Pass	Pass
12	Logitech	USB Mouse M-UAG120	Pass	Pass
13	Logitech	USB Mouse M-UV94	Pass	Pass
14	Logitech	USB Optical Mouse	Pass	Pass
15	Microsoft	Compact Optical Mouse M-000008	Pass	Pass
16	Microsoft	Wheel Mouse Optical USB and PS/2 Compatible X08-71118	Pass	Pass
17	Microsoft	X800898	Pass	Pass
18	Samsung	Acrox USB & PS/2 Mouse	Pass	Pass
19	Samsung	Pleomax PS/2+ USB Mouse	Pass	Pass
<b>Keyboard</b>				
20	BTC	8113W	Pass	Pass
21	BTC	8193C	Pass	Pass
22	Hewlett-Packard	KU-0316	Pass	Pass
23	Intopic	KDB-USB-10W	Pass	-
24	No Brand	PS/2 Mouse & Keyboard Connector to USB	Pass	Pass
<b>Joystick</b>				
25	DragonRise	Generic USB Joystick	Pass	Pass
26	Genesys	Genesys Logic	Pass	-
27	Logitech	Driving Force EX	Pass	Pass
28	Logitech	RumblePad 2 G-UF13	Pass	Pass
29	Logitech	WingMan Formula Force GP	Pass	Pass
30	Logitech	Wingman Strike Force 3D	Pass	Pass

**N/A : This USB Device does not have this function**

**- : Not Test (Only a certain function of this device was tested)**

**NS: This function is not supported.**

<b>NO Support</b>		
<b>No</b>	<b>Brand</b>	<b>Model Name</b>
<b>Bluetooth</b>		
1	Gigabyte	Bluetooth USB Dongle
<b>Cell phone</b>		
2	Dopod	585
3	Dopod	818 Pro
4	Nokia	6060
5	Motorola	RAZR V3
6	Sony Ericsson	W910i
<b>Scanner</b>		
7	Canon	CanoScan 5200 F
8	Pempower	WorldCard Ultra
9	Hewlett-Packard	Scanjet 4370